

PORTA-5

set_property PACKAGE_PIN L18 [get_ports {adc_out_1p[0]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_1p[0]}]

PORTA-6

set_property PACKAGE_PIN M25 [get_ports adc_fr_1p]

set_property IOSTANDARD LVDS [get_ports adc_fr_1p]

PORTA-7

set_property PACKAGE_PIN K18 [get_ports {adc_out_1n[0]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_1n[0]}]

PORTA-8

set_property PACKAGE_PIN M26 [get_ports adc_fr_1n]

set_property IOSTANDARD LVDS [get_ports adc_fr_1n]

PORTA-9

set_property PACKAGE_PIN M20 [get_ports {adc_out_1p[1]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_1p[1]}]

PORTA-10

set_property PACKAGE_PIN L24 [get_ports {adc_out_2p[0]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_2p[0]}]

PORTA-11

set_property PACKAGE_PIN M21 [get_ports {adc_out_1n[1]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_1n[1]}]

PORTA-12

set_property PACKAGE_PIN L25 [get_ports {adc_out_2n[0]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_2n[0]}]

PORTA-13

set_property PACKAGE_PIN J19 [get_ports adc_sdo_1]

set_property IOSTANDARD LVCMOS18 [get_ports adc_sdo_1]

PORTA-14

set_property PACKAGE_PIN K25 [get_ports {adc_out_2p[1]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_2p[1]}]

PORTA-15

set_property PACKAGE_PIN J20 [get_ports adc_cs_n_1]

set_property IOSTANDARD LVCMOS18 [get_ports adc_cs_n_1]

PORTA-16

set_property PACKAGE_PIN K26 [get_ports {adc_out_2n[1]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_2n[1]}]

PORTA-17

set_property PACKAGE_PIN L22 [get_ports adc_sck_1]

set_property IOSTANDARD LVCMOS18 [get_ports adc_sck_1]

PORTA-19

set_property PACKAGE_PIN L23 [get_ports adc_sdi_1]

set_property IOSTANDARD LVCMOS18 [get_ports adc_sdi_1]

PORTA-33

set_property PACKAGE_PIN J23 [get_ports adc_dco_1p]

set_property IOSTANDARD LVDS [get_ports adc_dco_1p]

PORTA-34

set_property PACKAGE_PIN H26 [get_ports adc_encode_1p]

set_property IOSTANDARD LVDS [get_ports adc_encode_1p]

PORTA-35

set_property PACKAGE_PIN J24 [get_ports adc_dco_1n]

set_property IOSTANDARD LVDS [get_ports adc_dco_1n]

PORTA-36

set_property PACKAGE_PIN G26 [get_ports adc_encode_1n]

set_property IOSTANDARD LVDS [get_ports adc_encode_1n]

#####

PORTB-5

set_property PACKAGE_PIN A22 [get_ports {adc_out_3p[0]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_3p[0]}]

PORTB-6

set_property PACKAGE_PIN A24 [get_ports adc_fr_2p]

set_property IOSTANDARD LVDS [get_ports adc_fr_2p]

PORTB-7

set_property PACKAGE_PIN A23 [get_ports {adc_out_3n[0]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_3n[0]}]

PORTB-8

set_property PACKAGE_PIN A25 [get_ports adc_fr_2n]

set_property IOSTANDARD LVDS [get_ports adc_fr_2n]

PORTB-9

set_property PACKAGE_PIN E21 [get_ports {adc_out_3p[1]}]

set_property IOSTANDARD LVDS [get_ports {adc_out_3p[1]}]

PORTB-10

```
set_property PACKAGE_PIN D24 [get_ports {adc_out_4p[0]}]
set_property IOSTANDARD LVDS [get_ports {adc_out_4p[0]}]
```

```
# PORTB-11
```

```
set_property PACKAGE_PIN D21 [get_ports {adc_out_3n[1]}]
set_property IOSTANDARD LVDS [get_ports {adc_out_3n[1]}]
```

```
# PORTB-12
```

```
set_property PACKAGE_PIN D25 [get_ports {adc_out_4n[0]}]
set_property IOSTANDARD LVDS [get_ports {adc_out_4n[0]}]
```

```
# PORTB-13
```

```
set_property PACKAGE_PIN E25 [get_ports adc_sdo_1]
set_property IOSTANDARD LVCMOS18 [get_ports adc_sdo_1]
```

```
# PORTB-14
```

```
set_property PACKAGE_PIN C23 [get_ports {adc_out_4p[1]}]
set_property IOSTANDARD LVDS [get_ports {adc_out_4p[1]}]
```

```
# PORTB-15
```

```
set_property PACKAGE_PIN E26 [get_ports adc_cs_n_2]
set_property IOSTANDARD LVCMOS18 [get_ports adc_cs_n_2]
```

```
# PORTB-16
```

```
set_property PACKAGE_PIN B24 [get_ports {adc_out_4n[1]}]
set_property IOSTANDARD LVDS [get_ports {adc_out_4n[1]}]
```

```
# PORTB-17
```

```
set_property PACKAGE_PIN F23 [get_ports adc_sck_2]
set_property IOSTANDARD LVCMOS18 [get_ports adc_sck_2]
```

PORTB-19

set_property PACKAGE_PIN E23 [get_ports adc_sdi_2]

set_property IOSTANDARD LVCMOS18 [get_ports adc_sdi_2]

PORTB-33

set_property PACKAGE_PIN G24 [get_ports adc_dco_2p]

set_property IOSTANDARD LVDS [get_ports adc_dco_2p]

PORTB-34

set_property PACKAGE_PIN H21 [get_ports adc_encode_2p]

set_property IOSTANDARD LVDS [get_ports adc_encode_2p]

PORTB-35

set_property PACKAGE_PIN G25 [get_ports adc_dco_2n]

set_property IOSTANDARD LVDS [get_ports adc_dco_2n]

PORTB-36

set_property PACKAGE_PIN H22 [get_ports adc_encode_2n]

set_property IOSTANDARD LVDS [get_ports adc_encode_2n]